



PFMTF50 Instruction



CHARGING BATTERY

WARNING: Never attempt to charge standard (non-rechargeable) batteries. Doing so could result in injury and will void the warranty.

This unit operates on one rechargeable 14500 Li-Ion battery (included) and we recommend fully charging it first. To do so, insert the battery into the home charger following the polarity diagram shown on the charger. Flip out the charging plug on the back of the charger and plug it into a standard wall outlet. **IMPORTANT: Do not charge for longer than 3 hours or continue to charge once the light on the charger turns green.** Once the light on the charger changes from red to green, the battery is fully charged and should be removed from the charger.

NOTE: PFMTF50 can use a standard AA battery (not included); however, the unit's performance will be limited to 1-2 hours. We highly recommend that you always use the included 14500 Li-Ion battery.

INSTALLING THE BATTERY

1. To access the battery compartment, unscrew the end cap (at the opposite end of the light) by turning it counterclockwise.

2. Insert the fully charged battery into the flashlight. The positive (+) end of the battery should be inserted first (toward the head of the light) as shown in the diagram below. Screw the end cap back on by turning it clockwise.



USING THE FLASHLIGHT

1. To turn on the light, press the rubber Push Button Tail Switch (located at the opposite end of the light) until it clicks and the light turns on. This unit features three light modes: High, Low, and Strobe.
2. To change the light mode, "soft press" the rubber Push Button Tail Switch by applying light pressure (if you press too hard it will click and turn off).
3. To adjust the focus, (with the light facing away from you) grasp the handle with one hand then use the other hand to move the Slide Zoom forward or backward.
4. To turn the flashlight off, press the rubber Push Button Tail Switch until it clicks.

WARRANTY

Cutting Edge Products, Inc. extends a Lifetime warranty to the **PFMTF50** for the product against defects in materials or workmanship, with the following exceptions:

1. The warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product, loss of parts, or recharging the unit in any manner not in accordance with the instructions above.
2. The warranty will be voided if the unit has been opened (with the exception of inserting the batteries according to the directions above) or tampered with in any way (unless by an Authorized Dealer) or if any unauthorized replacement parts have been used.
3. The lifetime warranty extends only to the flashlight and LED bulb only. The battery is excluded from the warranty because it will be damaged if the charging instructions above are not followed.

CONDITIONS OF SALE

Purchase of this product is an agreement by the purchaser/user to hold all sellers and manufacturers harmless of all liabilities and damages.

TO OBTAIN SERVICE

Contact the Authorized Dealer from whom you purchased this unit for Return Merchandise Authorization (RMA). The return unit must be sent postage prepaid and proof of purchase is required. Damage or loss occurring during shipment is not covered by this warranty.



PFMTF50 Instrucciones



CARGANDO LA BATERIA

ADVERTENCIA: Nunca intente cargar baterías estándar (no recargables). Si lo hace, podría provocar lesiones y anulará la garantía.

Esta unidad funciona con una batería recargable de ion de li-lon 14500 (*incluida*) y recomendamos cargarla completamente antes de usar. Para hacerlo, inserte la batería en el cargador siguiendo el diagrama de polaridad que se muestra en el cargador. Retire el enchufe de carga en la parte posterior del cargador y enchúfelo a un tomacorriente de pared estándar. **IMPORTANTE: no cargue durante más de 3 horas ni continúe cargando una vez que la luz del cargador se vuelva verde.** Una vez que la luz del cargador cambia de rojo a verde, la batería está completamente cargada y debe retirarse del cargador.

NOTA: PFMTF50 puede usar una batería AA estándar (no incluida); Sin embargo, el rendimiento de la unidad se limitará de 1-2 horas. Le recomendamos que siempre use la batería 14500 Li-Ion incluida.

INSTALANDO LA BATERIA

1. Para acceder al compartimiento de la batería, desenrosque la base (extremo opuesto de la luz) girando hacia la izquierda.

2. Inserte la batería ya cargada en la linterna. El lado positivo (+) de la batería debe insertarse primero. Coloque la base nuevamente girando la base hacia la derecha.



USANDO LA LINTERNA

1. Para encender la linterna, presione el botón táctico (ubicado en la base de la unidad) hasta que haga click y la luz se encienda. Esta unidad cuenta con tres modos de luz: alta, baja y luz estroboscópica.
2. Para cambiar el modo de luz, presione "suavemente" el botón táctico (si presiona fuertemente, escuchará "click" y la luz se apagará).
3. Para ajustar el enfoque, (no apunte la luz hacia usted), sujete la unidad con una mano y luego deslice el foco hacia adelante o hacia atrás.
4. Para, apagar la luz "presione fuertemente" el botón táctico hasta escuchar "click".

GARANTIA

Cutting Edge Products, Inc. ofrece garantía de por vida a la unidad **PFMTF50** contra defectos en materiales o mano de obra, con las siguientes excepciones:

1. La garantía no cubre los daños resultantes a la exposición en agua en exceso de la clasificación IP44, accidente, mal uso o abuso, falta de cuidado razonable, la colocación de cualquier accesorio no provisto con el producto, la pérdida de piezas o la recarga de la unidad de cualquier manera, no de acuerdo con las instrucciones anteriores
2. La garantía quedará anulada si la unidad es abierta (con la excepción de insertar la batería de acuerdo con las instrucciones anteriores) o se manipuló de alguna manera (a menos que haya sido realizada por un distribuidor autorizado) o si se han utilizado piezas de repuesto no autorizadas.
3. La garantía de por vida solo se aplica a la linterna y la bombilla LED. La batería está excluida de la garantía.

CONDICION DE VENTA

La compra de este producto es un acuerdo entre el comprador / vendedor de mantener a fabricantes y vendedores libres de toda responsabilidad y daños.

PARA OBTENER SERVICIO

Contacte el comercio autorizado donde obtuvo la unidad y requiera un numero de autorización de retorno. El retorno debe ser enviado con envío pago y prueba de compra. La pérdida de la unidad durante el envío no es cubierta por la garantía.