




SWSLHL
User Manual



LIGHT MODES

Standard White/Red Light Mode

Important: in this mode the Hand Wave (Smart Sensor) will not work. To change from white LEDs to red LEDs hold the **White/ Red Light Button** (top right) for 2 seconds. To change the light modes see below:

WHITE LIGHT MODES

- 1st Click. 100%- white light run time: 4 hours
- 2nd Click. 30%-white light run time:15 hours
- 3rd Click. 10%-white light run time: 30 hours
- 4th Click. Strobe
- 5th Click. Off

RED LIGHT MODES

- 1st Click Constant On
- 2nd Click Strobe

Smart Sensor Mode

Press the **Smart Sensor ON/OFF Button** (top left) and the top buttons will turn blue to confirm this mode. Now you can wave your hand in front of the headlamp to turn it ON or OFF. This feature will work in either 100% or 30% light.

- 1st Click 100% light Smart Sensor mode
- 2nd Click 30% light Smart Sensor mode
- 3rd Click Off



SPECIFICATIONS

Material	ABS	Battery	Built-in Li-Polymer Battery (3.7V/1200mAh)
Weight	70g		
Size	65x45x40mm	Features	Smart Sensor/Lightweight USB Rechargeable
Light Time	4h-30h		
Charge Time	4h		

CHARGING INSTRUCTIONS



Step 1	Remove the rubber cover. Using the included charging cord, insert the micro-USB plug into the charging port on the bottom of the headlamp as pictured above.
Step 2	Insert the standard USB end into a power source such as a computer or block charger if using an electrical outlet. The two top buttons will turn RED while charging.
Step 3	Charging is complete when the two top buttons change from RED to GREEN. Unplug the charging cord and replace the rubber cover.

- It is recommended that you fully charge the battery before using the headlamp.
- To prolong the life of the battery it is best to recharge the battery **BEFORE** it is fully discharged.
- Avoid extreme temperatures especially heat.
- **DO NOT** attempt to open the battery compartment as this could damage the unit and will void the warranty.

WARNING!

Looking directly at an LED light can harm your eyes. We do not recommend this product for children under 6 years old.

WARRANTY: *Streetwise Security Products* extends a One Year Warranty to the SWSLHL for the product against defects in materials or workmanship, with the following exceptions:

1. The warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product, loss of parts, or recharging the unit in any manner not in accordance with the instructions above.
2. The warranty will be voided if the unit has been opened or tampered with in any way (unless by an Authorized Dealer) or if any unauthorized replacement parts have been used.

Conditions of Sale: Purchase of this product is an agreement by the purchaser/user to hold all sellers and manufacturers harmless of all liabilities and damages.

To Obtain Service: Contact the Authorized Dealer from whom you purchased this unit for Return Merchandise Authorization (RMA). The return unit must be sent postage prepaid and proof of purchase is required. Damage or loss occurring during shipment is not covered by this warranty.