



## SMS16BK/PK Instruction Manual



### CHARGING THE BATTERIES

1. The rechargeable batteries are already installed. The unit cannot be opened, as this will void the warranty.
2. Before use, the stun gun will need to be charged for 8 hours. Insert the included charging cord into the bottom of the unit and the other end into your block charger (not included) then plug into a standard outlet. The Charging Indicator Light will come on while charging.

**IMPORTANT:** Do not charge for more than 8 hours at a time. **Overcharging can damage the unit and void the warranty.** Under normal use the unit will need to be recharged for 8 hours every 60 days. If the LED Flashlight is used frequently or if the electrical charge produced by the stun gun becomes noticeably weaker, the unit will need to be recharged.

### USING THE FLASHLIGHT

1. Slide the Safety Switch located on the side of the unit **up** to the middle position to turn on the LED Flashlight.
2. Slide the Safety Switch **down** to turn off the light.


### TESTING THE STUN GUN

**(WARNING: Do not test fire the stun gun for more than 1 second as this will damage the unit and void the warranty.)**

1. Slide the Safety Switch located on the side of the unit **up** to the top position to turn off the safety. The Stun Warning Light above the Safety Switch will illuminate.
2. Press the Stun Activation Button on the side of the unit (above the Safety Switch) to test the stun gun. You will see and hear an electrical charge fire across the top of the unit between the Test Probes.
3. When test firing the unit, do not hold the button down for more than 1 second. Slide the Safety Switch **down** to the bottom position to turn the safety back on. The Stun Warning Light will turn off.

## USING THE STUN GUN IN SELF DEFENSE

1. Slide the Safety Switch located on the side of the unit up to the top position to turn off the safety. The Stun Warning Light above the Safety Switch will illuminate.
2. Touch your assailant's body with the contact probes on the top of the unit and press the Stun Activation Button.
3. Touching anywhere on the assailant's body will have an effect; however, the maximum effect is achieved in the areas show to the right:
4. When touching the assailant's body, you will not see or hear the electrical charge as you do when the unit is test fired. You can hold down the Stun Activation Button for more than 1 second, as this will not damage the unit, as it will when being test fired.
5. You do not have to be concerned about the effects of the charge being transferred to you. Even if the assailant touches you while being stunned, you will not feel the effects of the charge.



## EFFECTS OF THE UNIT ON AN ASSAILANT

1. Touching an assailant for less than 1 second will cause minor muscle contractions and have a repelling effect.
2. Touching an assailant for 1 to 2 seconds will cause muscle spasms and a dazed mental state.
3. Touching an assailant for 3 to 5 seconds will cause loss of balance and muscle control, total mental confusion, and disorientation. All effects to the assailant are temporary; the stun gun can cause no permanent harm. (**NOTE:** The device should not be used for longer than 5 seconds.)

## WARRANTY

*Cutting Edge Products, Inc.* extends a lifetime warranty to the **SMS16BK/PK** against defects in materials or workmanship, with the following exceptions:

1. The warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, exposure to water or moisture, the affixing of any attachment not provided with the product, loss of parts, or recharging the unit in any manner not in accordance with the included instructions.
2. The warranty will be voided if the unit has been opened or tampered with in any way (unless by an authorized dealer) or if any unauthorized replacement parts have been used.

## NOTICE

Purchaser must check and abide by all local laws governing the possession and use of stun guns. In addition, the stun gun must only be used in a lawful manner for self-defense. **NOTE:** Not to be used on children, persons with heart disease, or any vital part of the human body. Not to be stored or used in environments where it is damp or humid or where there are extreme hot or cold temperatures. Do not use on metal objects.

## CONDITIONS OF SALE

Purchase of this product is an agreement by the purchaser/user to hold all sellers and manufacturers harmless of all liabilities and damages.

## TO OBTAIN SERVICE

Contact the Authorized Dealer from whom you purchased this unit for a Return Merchandise Authorization. The return unit must be sent postage prepaid and proof of purchase is required. Damage or loss occurring during shipment is not covered by this warranty.